

# **INSTALLATION GUIDE**50mm Range Two-Piece Batten

Achieve effortless architectural style with the cool, clean and contemporary lines of DecoBatten.


The light-weight aluminium battens replicate the form, feel and appearance of real timber thanks to the Super Durable™ DecoWood finish, offering a dimensionally stable, long-lasting timber alternative. DecoBatten allows for complete design flexibility and is suitable for a wide range of applications.

### **DecoBatten Design Options**

DecoBatten comes in two easy-to-install systems: the standard One-Piece system and the Two-Piece 'Quick Click' system. Both systems are available in a wide range of shapes and sizes and allow for multiple installation methods. One-Piece battens are generally used when fixing battens from behind and when fixings can be easily hidden. The Two-Piece 'Quick Click' system has been designed for easier and guicker installations of more difficult applications (walls, ceilings, etc) or where a seamless concealed fixing is desired.

### 50mm Range Batten

### 50mm Range Batten Bases



All DecoBatten and accessories are supplied in 6.5m lengths. As part of the manufacturing process, the first 10mm of both ends of the extrusion are taped and not imaged, therefore each board will need to be trimmed by 15mm on each end to remove the tape and provide a clean finish. After the removal of each end, the useable length is 6.47m. **Please note:** The usable length might be vary depending on the chosen finishes; please contact and discuss with your DECO representative for more information.

### Performance

As part of DECO's commitment to offering compliant building products, the DecoBatten systems have been designed to meet Australia's stringent building standards. The DecoBatten range has been tested to and passed the following standards:

DecoBatten - Tested Performance Data		
Description	Standard	Testing Body
Methods for fire tests on building materials, components and structures - Combustibility test for materials	AS1530.1	CSIRO
Methods for fire tests on building materials, components and structures - Simultaneous determination of ignitability, flame propagation, heat release and smoke release	AS/NZS1530.3	CSIRO
Method of test for heat and smoke release rates for materials and products using an oxygen consumption calorimeter	AS3837	CSIRO
DecoBatten - Assessed Performance Data		
Clause	Assessment Outcome	
NCC 2019 - Volume 1 - Clause C1.9 Non-Combustible building elements	Compliant	

**Please Note:** All testing has been undertaken using the detail provided in this installation guide and in order to claim the performances set out here within, the detail in this guide must be followed.

### **Engineering Performance**

Due to the extensive installation methods in which the DecoBatten systems can be applied, and the different requirements of each building type and location, it is recommended that users consult with their Architect, Engineer, Building Designer and Building Surveyor to ensure that the installation detail will suit the local regulations and requirements.

### **WARRANTY FOR DECO PRODUCTS AND FINISHES**

DECO Australia warrants that DECO finishes have been applied in accordance with the Australian Standard for Architectural Powder Coating AS 3715. The warranty is for 12 years and is subject to the provisions set out in AS 3715, including maintenance and cleaning, as set out in Appendix C of the standard.

**Please Note:** that if a formal warranty certificate is required, then this must be applied for at the time of order. This is because the standard AS3715 requires DECO Australia to process specimens for testing and reference at the same time as the job is processed. A warranty application form can be obtained by contacting DECO Australia by phone or email. Contact your DECO representative on (02) 9603 1888 for more information.

**Please Note:** The design of our Two-Piece batten systems may vary. The click, fixing and securing detail of each system may vary based on the design and product availability. Please discuss the specific details of each design with your DECO representative.

### **Intellectual Property**

This document and the information contained within it are copyright and confidential to DECO Australia. Disclosure, use and copying in any form, except as authorised by DECO Australia in writing are prohibited. Patents and Design Registrations Pending.



# INSTALLATION GUIDE End Caps


### **DecoBatten End Caps**

As a part of the DecoBatten range, End Caps are available to match your chosen batten profile. End Caps are available in colour-matched aluminium or black plastic for both the One-Piece and Two-Piece batten systems. NB: Depending on the selected profile, End Caps will be one of two types; extruded aluminium for 50mm and 25mm wide profiles or press-fit aluminium for all other profiles.


### **Extruded Aluminium End Caps**

Extruded aluminium End Caps are available for selected One-Piece and Two-Piece batten systems. Depending on the profile, the End Cap will be machined so that two legs fit into the profile and can be secured using a high-quality adhesive or mechanical fixings.

### End Cap for Two-Piece 50 x 50 Batten




### **End Cap Securing Options**



### **Adhesive Secure**

Apply high-quality adhesive to each of the legs as depicted and insert into the One-Piece Batten. Take care to ensure that no adhesive is applied to the visible surface of the extrusion or End Cap.

Ensure that the End Cap is securely fastened in place until the adhesive sets.



### **Mechanical Secure**


Fix in place with mechanical fixings such as screws or rivets through the outside of the section into one or more of the internal legs.

DECO recommends the use of stainless steel, galvanised or aluminium fixings. Colour-matched rivets are available to order.

Please Note: Pre-drilling are recommended for all mechanical fixing.

### **Press Fit Aluminium End Caps**

For all other profiles, press-fit aluminium End Caps are available for Two-Piece batten systems. Depending on the profile, the End Cap will be machined so that it fits snugly into the profile and can be secured using a high-quality adhesive.




### Adhesive Secure

Apply a high-quality adhesive to each of the legs as depicted and insert into the One-Piece Batten. Take care to ensure that the adhesive is not applied to the visible surface of the extrusion or End Cap.

Ensure that the End Cap is securely fastened in place until the adhesive sets

**Please Note:** May require light tapping with rubber mallet to install.





## **INSTALLATION GUIDE Standard Base**

### **Preparation**

### **Installation Surface**

When installing DecoBatten care should be taken to ensure the installation surface has been prepared adequately to ensure that it is fit for the intended purpose. The surface should also be clean and flat, and preparations (such as backing colour) should be applied before the installation of DecoBatten products.

#### Supporting Structure and Fixings


Before installing any DecoBatten products the supporting structure should be assessed to ensure that it is structurally sound and able to support live and dead loads of the DecoBatten products that are to be installed. When fixing DecoBatten products, it is recommended that they are fixed at minimum 600mm centres when applied to a solid backing or 450mm centres when applied to framing, however due to the wide variety of installation applications, this may not be required for all applications. DECO recommends that users contact a certified Engineer to assess the supporting structure and fixings required when installing DecoBatten, especially in high-wind and high-risk areas.

### **Processing of DecoBatten**


WARNING - When processing DecoBatten care should be taken and appropriate Personal Protective Equipment should be worn at all times. Failure to do so risks potential serious injury, disablement or death. When processing DecoBattens, care should be taken to ensure that the work space is clean and free from dust, sawdust, metal fines and/or shavings. Processing of the DecoBatten in areas with excessive dust, sawdust, metal fines and/or shavings risks potential damage to the finished surface.

### STEP 1 - Apply the Two-Piece Batten Base to the Supporting Structure and Fix as Required

If the batten is to be installed flush to an end surface, ensure at least 3mm of clearance are provided to allow the batten cover to click over the base. To ensure a straight, consistent and parallel installation, it is strongly recommended that a level is used to position each base.




### **Centre Fixing**



Fix with fasteners through the centre location aroove.

## **Dual Fixing**




Fix with fasteners through the outer two location arooves.

### STEP 2 - Install additional Two-Piece Bases and Fix as Required

To ensure equal consistent spacing between each batten, space the bases according to your desired finished spacing using the below formula.


- 1. X (spacing between bases) = Desired finished spacing + 4mm
- 2. Y (centre to centre spacing) = Desired finished spacing + 50mm





# **Spacing Dimensions**

### STEP 3 - Install Two-Piece Batten Covers and Fix as Required

Click the cover over each of the bases, ensuring a tight fit. Even though the DecoBatten product has been designed to ensure a secure click fit, if extra security against dislodgement is required, follow the detail provided below.








Prior to installation apply a bead of adhesive to the internal face of the step in the cover (as shown in DETAIL A) and click over the base. Ensure that the cover is secured in place until the adhesive sets.

## Screw or Rivet Fix



Apply screws or rivets as required through the cover and into the base in the position indicated by the location guides on the side of the cover.



# **INSTALLATION GUIDE**

### **SpaceBase**

### **Preparation**

### **Installation Surface**


When installing SpaceBase, care should be taken to ensure the installation surface has been prepared adequately to ensure that it is fit for the intended purpose. The surface should also be clean and flat, before the installation of SpaceBase.

### **Supporting Structure and Fixings**

Before installing SpaceBase/DecoBatten products, the supporting structure should be assessed to ensure that it is structurally sound and able to support live and dead loads of the SpaceBase/DecoBatten products that are to be installed. When fixing the SpaceBase, it is recommended that the bases are fixed at minimum 600mm centres when applied to a solid backing or 450mm centres when applied to framing. DECO recommends that users contact a certified Engineer to assess the supporting structure and fixings required when installing SpaceBase/DecoBatten, especially in high-wind and high-risk areas.

### **Processing of SpaceBase**

**WARNING** - When processing SpaceBase, care should be taken and appropriate Personal Protective Equipment should be worn at all times. Failure to do so risks potential serious injury, disablement or death. When processing SpaceBase, care should be taken to ensure that the work space is clean and free from dust, sawdust, metal fines and/or shavings. Processing of the SpaceBase in areas with excessive dust, sawdust, metal fines and/or shavings risks potential damage to the finished surface.




### Set up


50mm range SpaceBase provides a standard 50mm gap between battens after installing. However, the SpaceBase can also trimmed down from 50mm to 10mm to fit the user's needs

### STEP 1 - Apply the SpaceBase to the Supporting Structure and Fix as Required

If the batten is to be installed flush to an end surface, ensure at least 10mm of clearance are provided to allow the batten cover to click over the base. To ensure a straight, consistent and parallel installation, it is strongly recommended that a level is used to position each base.




### STEP 2 - Install additional SpaceBases and Fix as Required



### STEP 3 - Install Two-Piece Batten Covers and Fix as Required

Click the cover over each of the SpaceBases, ensuring a tight fit. Even though the DecoBatten product has been designed to ensure a secure click fit, if extra security against dislodgement is required, follow the detail provided below.





# **INSTALLATION GUIDE**End to End Concealed Fixing

### **Preparation**

### **Installation Surface**

When installing DecoBatten care should be taken to ensure the fixing surface has been prepared adequately to ensure that it is fit for the intended purpose. The fixing surface should also be clean and flat, and preparations (such as top and bottom wall colour) should be applied before the installation of DecoBatten products.

### **Supporting Structure and Fixings**

Before installing any DecoBatten products the supporting structure should be assessed to ensure that it is structurally sound and able to support live and dead loads of the DecoBatten products that are to be installed. DECO recommends that users contact a certified Engineer to assess the supporting structure and fixings required when installing DecoBatten, especially in high-wind and high-risk areas.

### **Processing of DecoBatten**

**WARNING -** When processing DecoBatten care should be taken and appropriate Personal Protective Equipment should be worn at all times. Failure to do so risks potential serious injury, disablement or death. When processing DecoBattens, care should be taken to ensure that the work space is clean and free from dust, sawdust, metal fines and/or shavings. Processing of the DecoBatten in areas with excessive dust, sawdust, metal fines and/or shavings risks potential damage to the finished surface.




### **End to End Concealed Fixing**

DecoBatten can be used in various applications. Using an end-to-end concealed fixing allows fixings to be concealed in applications such as the above image


# STEP 1 - Apply the Generic Fixing to the Supporting Structure and Fix as Required

While applying fixing on the top ensure it lines up to the bottom fixing.




### **STEP 2 - Fixing the Batten**


Locate and fix the batten cover toward the Generic Fixing on the top and bottom of the batten. (see in DETAIL B)



### STEP 3 - Install additional Two-Piece Batten Cover and Fix as Required

To ensure a straight, consistent and parallel installation, it is strongly recommended that a level is used to position each batten. For a consistent finish, ensure the battens cover are spaced apart evenly when installing. We recommend using a batten or other solid item for even spacing.





STEP 4 - Install the Two-Piece Batten Bases

